MAX24 Task

USER INSTRUCTIONS

HEIGHT ADJUST HEADREST
Lift to adjust

2D ARMRESTS
Height and width adjust

HEIGHT ADJUST LUMBAR SUPPORT & RATCHET HEIGHT ADJUST BACKREST

GAS LIFT
Raise and lower chair height

TILT TOCK
Forward to lock
Turn back to release

ARM WIDTH ADJUST
Push down to widen

SYNCHRO MECH
Turn handle clockwise to tension. Simple 4-position click system: soft, medium, firm, hard adjustment

SEAT SLIDER
Allows seat depth adjustment

IMPORTANT MAINTENANCE & CARE:

You MUST check all bolts/screws and hand-tighten them at least once every six months. Your chair has moving parts and screws can loosen over time. Faults, damage, breakage or injury can occur if your chair is not maintained. If faults are found to be from lack of care and/or maintenance, no liability will be accepted.