



IMPORTANT MAINTENANCE & CARE:

You MUST check all bolts/screws and hand-tighten them at least once every six months. Your chair has moving parts and screws can loosen over time. Faults, damage, breakage or injury can occur if your chair is not maintained. If faults are found to be from lack of care and/or maintenance, no liability will be accepted.